


P SEA CONCEPTS™
P SEA CONNECT™ 6-PORT SWITCH
Model MES-6P
INSTALLATION INSTRUCTIONS



1. Locate the position to mount the MES-6P.
2. Connect the +12V power cord to vessel power and GND wire to ground, either switched or continuous +12V.
3. Connect Ethernet cables as required for external devices.
(any port can be used)

Thank you For using,
P SEA VISION™ PRODUCTS
P SEA CONCEPTS™ Copyright 1999-2003